




Hello

Quick Start Guide

A diagram illustrating the connection of a MacBook Air to an AC power source. The top part shows a white power adapter with an 'AC plug' on the left and a 'Power adapter' on the right, connected by a cable. The bottom part shows the MacBook Air with its 'AC power cord' connected to the 'MagSafe 2 power connector' on the left side. The 'Power button' is located on the right side of the laptop. The 'Multi-Touch trackpad' is at the bottom center. Dotted lines with labels point to each component: 'AC plug', 'Power adapter', 'AC power cord', 'Power button', 'MagSafe 2 power connector', and 'Multi-Touch trackpad'.

The image shows a silver MacBook Pro laptop with its screen open, displaying the Apple Setup Assistant. The main window is a 'Welcome' screen with the word 'Welcome' repeated in various languages: English, Swedish, Spanish, Portuguese, Korean, French, German, Italian, Dutch, and Chinese. Below the language text, there is a blue rectangular button with the text 'View English (the main language)' and a list of other language options: 'Español (España)', 'Français (France)', 'Deutsch (Deutschland)', 'Italiano (Italia)', 'Nederlands (Nederland)', 'Português (Brasil)', 'Korean (Korea)', and '中文 (中国)'. At the bottom of the screen, there is a small note: 'By using this software, you agree to the terms of the software license agreement for the software. You can view the terms of the software license agreement at <http://www.apple.com/legal/rsa.html>'.

A laptop screen displaying the 'Transfer Information to This Mac' setup window. The window shows options for transferring data from another Mac, a Windows PC, or a Time Machine backup. The 'From another Mac' option is selected. At the bottom, there are 'Back' and 'Continue' buttons.

<b>Multi-Touch gestures</b>	
	<p>You can do a lot of things on your MacBook Pro using simple gestures on the trackpad. Here are some of the most popular ones.</p>
	<p><b>Click</b> Press down anywhere on the trackpad to click. Or, with Tap to Click enabled, simply tap the surface.</p>
	<p><b>Double click</b> Press down two times anywhere on the trackpad. Or, with Tap to Click enabled, double-tap the surface.</p>
	<p><b>Secondary click (right click)</b> Click with two fingers to open shortcut menus. Or, with Tap to Click enabled, tap two fingers anywhere.</p>
	<p><b>Two-finger scroll</b> Brush two fingers along the trackpad to scroll in any direction—up, down, or sideways.</p>
	<p><b>Swipe to navigate</b> Swipe with two fingers to flip through web pages, documents, and more.</p>
	<p><b>Smart zoom</b> Double-tap the trackpad with two fingers to quickly magnify a web page.</p>

**Pinch to zoom**  
Zoom in and out of photos and web pages more precisely by pinching your thumb and finger.

**Rotate**  
Turn your thumb and finger clockwise or counterclockwise to rotate an image.

**Switch between full-screen apps**  
Swipe with three fingers to move from one full-screen app to another.

**View Mission Control**  
Swipe up with three fingers to see every open window on your Mac.

**View Launchpad**  
Pinch with four fingers to view all your apps in Launchpad.

**Learn more**  
Choose System Preferences from the Apple menu and click Trackpad to learn more about gestures.

The image shows a Mac desktop with a starry galaxy wallpaper. Several UI elements are labeled with callout lines:

- Help menu:** Points to the "Help" menu in the top-left corner of the menu bar.
- Menu bar:** Points to the top horizontal bar containing the Apple logo, menu items (File, Edit, View, Go, Window, Help), and system status icons.
- Wi-Fi status:** Points to the Wi-Fi signal icon in the top-right corner of the menu bar, with a tooltip showing "Turn Wi-Fi Off".
- Finder:** Points to the icon in the Dock.
- Dock:** Points to the horizontal bar at the bottom of the screen containing icons for various applications.
- System Preferences:** Points to the gear icon in the Dock.

A photograph of a silver Mac laptop. The screen displays the 'System Preferences' window with the 'iCloud' pane selected. The pane lists several services: Mail & Notes, Contacts, Calendars, Bookmarks, Photo Stream, Documents & Data, Back to My Mac, and Find My Mac. The desktop background is a blue space-themed image with stars. The dock at the bottom of the screen shows various application icons.

**An important note**  
Please read this document and the safety information in the Important Product Information Guide carefully before you first use your computer.

**Learn more**  
You can find more information, watch demos, and learn even more about MacBook Pro features at [www.apple.com/macbookpro](http://www.apple.com/macbookpro).

**Help**  
You can often find answers to your questions, as well as instructions and troubleshooting information, in Help Center. Click the Finder icon, click Help in the menu bar, and choose Help Center.

**Mac OS X Utilities**  
If you have a problem with your Mac, Mac OS X Utilities can help you repair your computer's flash storage, restore your software and data from a Time Machine backup, or erase your flash storage and reinstall OS X Lion and Apple applications. You can also use Safari to get online help. If your Mac detects a problem, it opens Mac OS X Utilities automatically. Or you can open it manually by restarting your computer while holding down the Command and R keys.

**Support**  
Your MacBook Pro comes with 90 days of technical support and one year of hardware repair warranty coverage at an Apple Retail Store or an Apple Authorized Service Provider. Visit [www.apple.com/support/macbookpro](http://www.apple.com/support/macbookpro) for MacBook Pro technical support. Or call **1-800-275-2273**. In Canada, call **1-800-263-3394**.

Not all features are available in all areas.

TM and © 2012 Apple Inc. All rights reserved. Designed by Apple in California. Printed in XXXX.  
034-6358-A

